

C5 Corvette LED Map Lights (1997-1999 only)

Tools needed:

- Small flat head screwdriver
- Needle nose pliers

1. Before starting please remove fuse #2 and #29 in the passenger foot well fuse box, or if you don't want to do that you can just disconnected your battery.
2. Take your small flat head screw driver and pop out both lens from the mirror as show below. Also remove the stock light using your screw driver or needle nose pliers.





3. Remove this metal piece shown in the picture below where it says "place screw driver here" below do that and pry up which will pop this out, use your needle nose pliers if needed to grab it out.



4. Grab the new led with your needle nose pliers and make sure that the led's are facing down so when you install it the light will shine directly down.



5. Push the led into the two electrical connections and make sure the led's are still positioned pointing straight down. Repeat these steps for both sides of the mirror then when you are all done put back in your fuses or connect your battery and test the lights. If for any reason they do not work insure that the electrical connections and the led tips are clean from any dirt.

6. Replace the clear lens cover as show below starting with this side in first then pushing the other side in.





Thank you for your purchase and enjoy!

Greg Sanders

Sales@GScrationsLLC.com

www.GScrationsllc.com