

## **C6 Corvette Driving Light Blackout Instructions**

- To install these blackouts you simply need to press them into place. They are slightly larger than the lens.
- Peel the backing from the tape.
- Take the cover and slide it to once side until it snaps between the lens and the body of the car. Make sure to keep the tape from touching until you get the cover into place.
- Now press he cover into place and keep pressure for one minute.
- Repeat this step on the other side.

Thank you for got purchase and enjoy!

GSc creations



GSCREATIONS