

GScreations C6 Rear Clear Side Markers

Tools needed:



Torx T15 bit

Or



Small flat head screw driver that will fit inside the star groove.

1) To remove the rear OEM side marker remove the outer most tail light. Use the Torx T15 bit as shown above or a small flat head screw driver to remove the screw located on the underside top of the tail light. Then you will be able to reach your arm inside the fender, pinch and push the front clip first then the rear clip on the side marker to pop it out.





2) Remove the light attached by wire by twisting it out.



3) Put the light in your new clear side marker housings and twist in. If you are replacing the stock bulb with our LED's please be sure to turn the lights on before you put everything back together to test you have it in correct. If it doesn't light up take the new led out and turn it around. They will only light up if installed one way.

4) Pop your new clear side marker into place and replace the tail light you just removed.

5) Repeat this for the other side.

Thank you for your purchase and enjoy!

Sales@GScreationsLLC.com



