

Camaro Front Blackout installation instructions

The Passenger side blackout is the one with the sticker on it.

Please note: The insulation of these blackouts are accomplished by sliding them in from the front of the light on the outside of the car. Please use care as there is always a risk of either breaking the blackout or scratching your front bumper if you aren't very careful.

Step 1:



Step 2:

Start with the passenger side (**The Passenger side blackout is the one with the sticker on it**) Remove sticker, take the back side of the blackout and insert it up and into the bumper as shown below.



Step 3:
Keep sliding the blackout lens up, in and back as shown below.



Step 4:

Now with the front of the blackout in position begin to pull down using just your fingers on both hands to bring the blackout lens down and level with the light as step 5 will show.



Step 5:

Align and straighten out the lens so it's even and looks like this below. Repeat for the drivers side then sit back and take a look how mean your Camaro looks now, you are done!

GSCREATIONS



If you have any questions please don't hesitate to send us an E-mail, We will be more than happy to assist you.

Thank you for your purchase and enjoy!

Sales@GScrationsLLC.com

www.GScrationsLLC.com

E-bay name: Gst20psi

