

Corvette Blackout installation instructions

Back Lights

Tools needed:

- T-15 Torx bit (you may be able to use a small flat head screwdriver if you don't have the Torx bit)

Taillights:

- 1) Remove Torx screws from each taillight (2) for each light.
- 2) Insert one side at a time (**not both at once, it won't fit**) It's a tight secure fit once in. They were designed to take up the entire space and not just cover the red lens.
- 3) Reuse the T-15 stock screws but be sure **not** to tighten too much or you may risk breaking the blackout. ☹

Reverse & 3rd brake light

- 1) Remove red plastic film from each piece of the 3m tape, carefully line up and press to the light while applying firm pressure for about 10 seconds. **Please note this is clear 3m tape so you won't see any tape outlines when you hit your brakes or use your reverse lights.**
- 2) Wash hands and enjoy!!!!

Thank you for your purchase and enjoy!

Greg Sanders

Sales@GSc creationsLLC.com

GSc creationsllc.com

GSCREATIONS