

C5 Corvette License Plate LED lights

Tools needed:

- T-15 Torx bit (you may be able to use a small flat head screwdriver if you don't have the Torx bit)

1. Remove the 4 Torx screws from the stock housings. These stock light housings can be removed without removing your license plate frame & bracket. Leave them hanging down in front of your license plate.
2. Untwist the stock bulb receptacle from the light housings. Remove the bulbs from the receptacles and insert your new LED plugs into the receptacles. Turn on your parking lights to check for proper connections. If the LED's are not lit rotate the led connection in the receptacle 180 degrees.

You're new LED's come supplied with 3m tape for an easy installation. These LED's will fit the stock mounting locations but this will leave you with a uneven spread of light. Stick with using the tape mounting option.

3. You will want to mount the LED's 3.5" apart from each other; this will give you the best look. Use the supplied alcohol to clean the area where the LED's will be placed and Let dry for about 2-3 minutes. This is a very important step and failure to do so or let dry will cause the LED's to not stick. Remove the red tape backing and press on for 15-20 seconds.

GS CREATIONS



Thank you for your purchase and enjoy!

Greg Sanders

Sales@GScrationsLLC.com

www.GScrationsllc.com

GSCREATIONS