

Package Contents:

3-Piece Carbon Fiber Trim Kit with 3m adhesive backing.

Alcohol Wipes

Installation:

(Professional installation is always recommended)

1. The first thing you will want to do **BEFORE** removing the adhesive backing, is individually dry fit each carbon fiber piece over the chrome dash trim, so you get an idea of how it will fit and how to tuck the edge on one of the pieces.

The left side of the carbon fiber piece above the glove box may need to be tucked slightly behind the leather on the dash. Again, it's important do a dry fit before exposing the adhesive backing, in order to ensure proper placement of this piece.



2. Open one of the alcohol wipe packets and thoroughly wipe down all of the chrome pieces. Wait about 30 seconds (or until dry).

3. Select the carbon fiber trim piece that covers the area you just cleaned. Remove the paper backing to fully expose the 3M adhesive.

4. Carefully place and press the carbon fiber piece down firmly over the chrome trim.

5. Repeat steps 2-4 for the other two pieces