

Installing C5 Corvette Rear Vent Screens

Installation Time: 10-30 min.

1. Jacking up the rear of your car might make it easier for you to crawl under your car. Please use jack stands if you decide to go this route.
2. The screens are labeled right and left respectively
3. Test fit the screens before you remove the tape backing and install so you will know how they will sit when you mount them.
4. Use the provided alcohol pads to clear the mounting surface were the screens will mount. **Please allow the alcohol to dry for 5 minutes before you mount the screens.** When dry remove the tape backing that will touch the inner bumper and carefully mount the screens. Press down on the top and press up on the bottom of the screens to "sandwich" the inner rear bumper and insure a tight fit.

Thank you for your purchase and enjoy!

Greg Sanders GS Creations, LLC

www.GSCreationsllc.com

(We can get you ANY GM, MAZDA or INFINITI part for under dealer cost!!! Just email us with what part you need)

GS CREATIONS