

Installing C5 Corvette Side Vent Screens

Tools: 7mm Socket/ratchet

Installation Time: 10-30 min.

1. You may either gain access to install the screens by turning the front wheels left (on the driver's side) and right (passenger side) Or by removing the front wheels.
2. Remove the 7mm screws and 1 plastic push in retainer for the rearward inner fender wheel well. When the panel is removed, remove the two 7mm screws that retain the side vent deflector then take out that vent deflector to get a better view and access of the side vent hole.



3. Both screens are the same for either side; please test fit the screens before taking the tape backing off so you are familiar with how they will be positioned. Use the provided alcohol pads to clear the inner fender surface where the screen will mount. **Please allow the alcohol to dry for 5 minutes before you mount the screens.** When dry remove the tape backing that will touch the fender and carefully mount the screens.



Thank you for your purchase and enjoy!

Greg Sanders GS Creations, LLC

www.GSCreationsllc.com

(We can get you ANY GM, MAZDA or INFINITI part for under dealer cost!!! Just email us with what part you need)

GS CREATIONS