LS2/LS3 Fuel rail name change plate and letter kit

- 1. Clean factory fuel rail cover where cover plate and LS2/LS3 letters will be installed with supplied alcohol. Let dry for 5 mins.
- 2. Remove the red 3m tape backing from "Corvette" area long rectangle cover plate, line up so it's even from left to right spacing and adhere onto the cover.
- 3.Remove the red 3m tape from each new letter insert and gently press them into place. When all letters are in place remove the top brown paper protective coating from the letters. ONLY CLEAN letters with soapy water, DO NOT USE alcohol or any alcohol based cleaning product to clean the letters at any time.

Thank you for your purchase, please share your new look with our social media fans.

Instagram.com/GScreations Facebook.com/GScreationsllc

