

1998 -2002 Trans Am Turn Blackout kit Install

Kit Contents:

- 2- Turn Signal Blackouts
- 2-Driving light Blackouts

Turn Signal install section:

The blackout covers are held in on one side with the hook shape in the acrylic. The other side is a squeeze fit.

1. Slide the blackout cover in at a slight angle with the top of the cover going in first.
2. Then push the entire blackout cover inward so it is flush with the driving light
3. When the blackout cover is flush against the driving light then slide downward until the cover is perfectly in place.

This picture shows where on the blackout cover that you will see the little hook shape; this is what was designed to hold the cover in place.



Center driving light install section:

The inside area of the opening for the driving light on your Trans Am has a V shaped slot at the top (12:00 position.)



When you install the cover push the bottom side in first (6:00 position) then just push the top part in till flush with the light. It will fit firmly and will not rattle or fall out if installed correctly.

Removal:

If for any reason you need to remove the blackouts here is how. The first time will be a little tricky. Use your index finger and push firmly onto the blackout cover at the top (12:00 position) Use an upward motion and the lower side of the lens will pop away from the light enough to pull out.

Thank you for your purchase and enjoy!

Greg Sanders

GS Creations, LLC

www.GSCreationsllc.com

(We can get you ANY GM part for under dealer cost!!! Just email me with what part you need)