

C6 Corvette Shift Knob Made To Fit The 1997-2004 C5 Corvette

1) Pry up the shift pattern with a small screwdriver very carefully. Now, using a pair of Vice Grips, grip the retaining pin tightly and pull the retainer up and out of the knob. You may have to rock the Vice Grips back and forth a little to get it all the way out. Just be careful not to damage anything else. Once the pin is out you can unscrew the knob off of the shifter handle. Go ahead and remove it.







2) Now place your new C6 knob onto the shifter press down and turn clockwise until tight and in the correct location for you. **Do not over tighten.**



Thank you for your purchase and enjoy!

Greg Sanders

Sales@GSc creationsLLC.com

www.GSc creationsLLC.com